



---

## Changes and Improvements in SkyElite v1.3

---

**All the new features listed in this document are explained in the SkyElite Manual**

### **Updating an existing installation**

- **Do not uninstall previous version of SkyElite software. The installer will update current installation.**
- Always backup your current SkyElite folder, it could be needed in case something goes wrong with the installation.
- Be sure SkyElite is not running during the update process.

### **List of new features included in v1.3**

- New SE1000 AHRS mode in PFD menu.
- SE1000 mode settings in settings menu.
- ADF and Engine indicator locations changed to fit in the new design.
- Green or Brown Ground AHRS modes in menu options.
- Custom Reference Speeds editor in settings menu. This feature affects to SkyElite only.
- AIMOS USB Knobs supported for AP and MAP operations.  
[Read included SkyElite Knob Manual.pdf document for additional knob information](#)
- MUSIC now stores selected station and volume in the selected profile.
- Map icons and markers fully redesigned, now more realistic standard design.
- Map wind indicator redesigned.
- Airport runway length information now also displayed in feet.
- New selected altitude visual alert when reaching target altitude.
- NEAR, W-ILS, LIGHT airport functions now sorted by distance.
- All bugs reported before the release are now fixed.

### **Disclaimer**

- SkyElite version updates will be periodically released and published in order to fix reported known issues and to add improvements or new features to the current version of the software.
- Be aware that not all of the new features will be totally compatible with all devices. Some features may work partially or even not work for some devices.
- SkyElite is developed under the web standards to be compatible with major part of the web browsers and devices in the market, but we cannot 100% guarantee that all of the features will work perfectly for all the devices.